



arlo™

Arlo Pro Add-On Camera
Quick Start Guide



Welcome

Thank you for choosing Arlo Pro.
Getting started is easy.


What's Included



Arlo Pro Wire-Free camera



Rechargeable battery



Power adapter



Magnetic wall mount



Mounting screw



Power adapter cable

Insert the Battery

1. Unlock the battery compartment by pressing and holding the latch.
2. Gently pull the battery door back to open the compartment.
3. Align the battery contacts.
4. Insert the battery.
5. Close the battery door.



Sync Your Camera With the Base Station

1. Bring the camera within 1 to 3 feet (30 to 100 centimeters) of the base station.

Note: Cameras must be synced one at a time.



2. Press the **Sync** button on the top of the base station for about two seconds. Release the button.
3. Wait for the Sync Status LED to blink green.



4. Press the **Sync** button on top of the camera for about two seconds. Release the button.



A blue LED on the camera blinks slowly when the sync process starts. A blue LED on the camera blinks rapidly to confirm sync.

The camera is ready for viewing.

Note: The LED blinks amber if the sync is not successful. You must repeat the sync process.



Charge Your Arlo Pro Battery

The Arlo Pro battery is fully charged when it leaves the factory.

➤ If you need to recharge the battery:


1. Place the camera indoors.

If you are using the camera outside, bring it inside while charging the battery.

2. Connect the power adapter cable to the camera power adapter.

Note: You must use an Arlo Pro power adapter and cable to charge the battery.

3. Connect the other end of the adapter cable to the camera.
4. Plug the power adapter into an electrical outlet.



The camera LED lights solid blue when the camera battery is fully charged.



You're Done!

Congratulations! Your Arlo camera is set up and ready to go. To view useful tutorial videos, find troubleshooting tips, or get support, visit <http://support.arlo.com>.

Camera LED Guide



General

- **Blink blue once**
The camera is powered on.
- **Blinking blue and amber**
A firmware update is in progress. DO NOT TURN OFF THE CAMERA.
- **Off**
The camera is either powered off or is powered on and is synced to a base station.

Syncing

- ☀ **Slow blinking blue**
The camera is searching for a base station.
- ☀ **Fast blinking blue**
The camera is syncing with a base station.
- ☀ **Fast blinking amber**
The camera did not sync properly.

Charging

- ☀ **Fast blinking blue**
The camera is connected to power.
- **Solid blue**
The camera is powered on and the battery is fully charged.
- ☀ **Slow blinking amber**
The camera battery charge is low.
- ☀ **Fast blinking amber**
The power connection failed.

©NETGEAR, Inc., NETGEAR, the NETGEAR Logo, and Arlo are trademarks of NETGEAR, Inc.

Compliance

For the current EU Declaration of Conformity,
visit http://kb.netgear.com/app/answers/detail/a_id/11621/.

For regulatory compliance information,
visit <http://www.netgear.com/about/regulatory/>.

NETGEAR®

350 East Plumeria Drive
San Jose, CA 95134, USA



201-20428-02



NETGEAR INTL LTD

Building 3, University Technology Center
Curraheen Road, Cork, Ireland

October 2016